


## INDICATING CHECK SWITCH and TRACK DEAD SECTION



### OPERATION

With the switch in the 'Off' position, the centre rail of the dead section is live, so the train travels normally.

With the switch in the 'On' position, a small bulb inside the switch is connected in series with the centre rail. The bulb acts as a resistance, so the train slows down and the bulb lights to show a train is in the dead section.

The dead section can be several lengths of track, a siding, main line or a loop.

### ADDITIONAL

The Trix 'Block Signalling Set' adds two colour light signals. A 'Distant' signal is placed at the start of the dead section to warn that the train might stop, and a 'Home' signal is placed at the end to show 'all clear'. These signals are controlled by two yellow switches that are ganged to the Indicating Check Switch.