



MP1 Carbon + Gauze Brushes - Special Note

The brushes now supplied for use with 14V a.c. Trix motors are actually Marklin pattern. They may be used with original Trix brush springs if in good condition, or with TTRCA MP2A springs. Always use carbon and copper gauze brushes in pairs. NEVER use two gauze brushes.

Occasionally, the new gauze brushes are too large in diameter to fit into the brush holder tube. If this is the case the easiest cure is to roll the new brush between thumb and forefinger (in the right direction) so as to tighten the winding of the gauze. Only as a last resort should it be necessary to trim a few millimetres off the outside turn.